

# Zoom Out

### **No. 1348-406 LEFT CHAISE** W 60 D 38 H 25 in.

Seat depth 24 in. Seat height 18 in.

# No. 1348-104 CORNER CHAIR

W 38 D 38 H 25 in. Seat depth 24 in. Seat height 18 in.

#### No. 1348-100 ARMLESS CHAIR

W 36 D 38 H 25 in. Seat depth 24 in. Seat height 18 in.

## No. 1348-102 RAF CHAIR

W 41 D 38 H 25 in. Seat depth 24 in. Seat height 18 in. Arm height 23<sup>1</sup>/<sub>2</sub> in. Arm width 6 in.



Height to top of back cushion 33 in. approx.

