

# Stressless® Emily




Stressless® Emily Steel Arm with Longseat (L) and Center Module shown in Paloma Espresso



## Available Modules:



- You will need 3.1" behind the sofa for the Stressless reclining function.
- Power operated headrests are standard on the Emily Corner unit (one on each side). Battery pack is optional; you need one battery pack for each module. The corner headrests are operated by two motors. You only need one transformer to power the two headrests.
- Cannot operate Power seats on both sides of the Emily Corner simultaneously. The footrests will collide if you do.
- Emily Center Module can be placed between any two modules. The Center Module, End Left Module and End Right Module cannot be setup as stand alone modules; they must be connected to a seat or corner. You cannot mount an armrest directly on the Corner Module or space modules.
- Emily End Modules can replace the armrest(s) on a sofa setup.
- All modules are delivered with 3.15 in wood legs in black which are barely visible. The armrests have the visible legs, and all models come with more than one version of the armrest (upholstered, steel or wood; depending on the model).



Available in over 50 leather colors combined with 8 wood finish choices.



Steel: Chrome



Steel: Matte Black



Wood



Wide


# Stressless® Emily




Stressless® Emily Wide Arm with Longseat (M) shown in Paloma Almond

Left/Right	Center	Chair	2-Seater	3-Seater	4-Seater	Corner	Modules
Steel: 33.9" Wood: 34.3" Wide: 39"	Steel: 30" Wood: 30" Wide: 30"	Steel: 37.8" Wood: 38.6" Wide: 48"	Steel: 67.7" Wood: 68.5" Wide: 77.6	Steel: 97.6" Wood: 98.4" Wide: 107.1"	Steel: 127.6" Wood: 128.3" Wide: 136.6"	48.8"	19.7"

### Left/Right/Center Seats and Chair:




### Longseat (M and L):



- Longseat (M) w/ Arms Width  
Steel: 37.8" Wood: 38.9" Wide: 48"
- Longseat (M) w/ Left/Right Arm Width  
Steel: 33.9" Wood: 34.3" Wide: 39"
- Longseat (L) w/ Arms Width  
Steel: 47.2" Wood: 52.4" Wide: 61.8"
- Longseat (L) w/ Left/Right Arm Width  
Steel: 47.2" Wood: 47.6" Wide: 52.4"

### Stressless® Emily Configuration Examples



Ⓟ ANY Left, Right and Center Seats have the option of Power Recline